

HOW TO MEASURE

JOBST® FarrowWrap® RTW Legpiece size chart

		XSmall	Small	Medium	Large	XLarge
Ready-to-wear pieces						
Legpiece						
C	Calf	36-43 cm	42-50 cm	48-58 cm	53-63 cm	58-68 cm
B	Ankle	21-25 cm	25-30 cm	30-36 cm	36-42 cm	42-50 cm
A-D	Regular	35-39 cm	37-41 cm	39-43 cm	41-45 cm	42-46 cm
A-D	Tall	40-44 cm	42-46 cm	44-48 cm	46-50 cm	47-51 cm
Length A-D = Floor to 2 finger widths below crease of knee. Measure posteriorly FOLLOWING contour of leg.						

JOBST® FarrowWrap® RTW Footpiece size chart




		XSmall	Small	Medium	Large	XLarge
Ready-to-wear pieces						
Footpiece						
A	Mid-foot	22-24 cm	25-27 cm	28-30 cm	31-34 cm	35-40 cm
X	Regular	15-17 cm	16-19 cm	18-20 cm	19-22 cm	21-24 cm
X	Tall	18-20 cm	20-22 cm	21-23 cm	23-25 cm	25-27 cm
The length is measured from the most posterior aspect of the heel to the base of the 5th toe.						


JOBST® FarrowWrap® RTW Thighpiece size chart

		XSmall	Small	Medium	Large	XLarge
Ready-to-wear pieces						
Thighpiece						
G	Groin	60-70 cm	65-75 cm	70-80 cm	75-90 cm	85-100 cm
E	Above Knee	47-52 cm	53-59 cm	60-66 cm	67-73 cm	74-80 cm
E-G	Short	16-20 cm	16-20 cm	16-20 cm	16-20 cm	16-20 cm
E-G	Regular	21-26 cm	21-26 cm	21-26 cm	21-26 cm	21-26 cm
E-G	Tall	27-31 cm	27-31 cm	27-31 cm	27-31 cm	27-31 cm
Length E-G = Measure MEDIALLY from just above patella to the groin. Follow outer contour of any skin folds/lobules.						

HOW TO MEASURE

JOBST® FarrowWrap® RTW Armsleeve size chart

	Wrist	Elbow	Axilla
			
Small	14cm - 18cm	20cm - 27cm	22cm - 31cm
Medium	16cm - 21cm	25cm - 34cm	29cm - 39cm
Large	19cm - 25cm	30cm - 40cm	32cm - 45cm




	Length
Short	40cm - 43cm
Regular	44cm - 47cm
Long	48cm - 51cm

NOTE: Measure length along the lateral outer arm from the wrist to the axilla with a slight bend in the arm.

JOBST® FarrowWrap® RTW Gauntlet sizing chart

	Xsmall	Small	Medium	Large
A	16cm - 18cm	18cm - 20cm	20cm - 22cm	22cm - 24cm
B	17cm - 19cm	19cm - 21cm	21cm - 23cm	23cm - 26cm
C	15cm - 18cm	17cm - 20cm	19cm - 22cm	22cm - 24cm



Jobst® FarrowWrap® Liner sizing chart

Terry Cloth Liners

Can accommodate the following calf circumferences:
Small (>40 cm), Medium (40-70 cm) and Large (70-120 cm).

Silver Liners

Small – Can accommodate calf circumferences to 60cm.
Large – Can accommodate calf circumferences to 70cm.

Hybrid Liners

Measure the mid foot A circumference.

Two mid foot sizes available:
20-27cm (regular foot) and 28-35cm (wide foot).

Request the patients shoe size (US Sizing).

	Small	Medium	Large	XLarge
Male Shoe Size	3-6	7-9	10-12	13-15
Female Shoe Size	4-7	8-10	11-13	14-16

Note the maximum calf size for Hybrid Liners is 60cm

Jobst® FarrowWrap® Knee piece sizing chart

	Xsmall	Small	Medium	Large	X Large
5cm above patella	47 - 52cm	53 - 59cm	60 - 66cm	67 - 73cm	74 - 80cm
Calf	36 - 43cm	42 - 50cm	48 - 58cm	53 - 63cm	58 - 68cm